



CYCLEDELIK B2B CARGOBIKE SERVICE & SAFETY* CHECKLIST	900 Miles or 3 months*	1800 Miles or 6 months*	2700 Miles or 9 months*	3600 Miles or 12 months*	4500 Miles or 15 months*	5400 Miles or 18 months*	6300 Miles or 21 months*	7200 Miles or 24 months*
	Full Service (Change)				Full Service (Change)			
Tyre tread depth (minimal is 1mm) and for damage. Replace if necessary.	Check/change	Check/change	Check/change	Check/change*	Check/change	Check/change	Check/change	Check/change*
Chains (tension/damage/lubrication)	Check/adjust	Check/adjust	Check/adjust	Change*	Check/adjust	Check/adjust	Check/adjust	Change*
Cockpit / Windshield / Wipers	Check/adjust	Check/adjust	Check/adjust	Check/adjust*	Check/adjust	Check/adjust	Check/adjust	Check/adjust*
Ebike controls and peripherals integrity & functionality	Check/adjust	Check/adjust	Check/adjust	Check/change*	Check/adjust	Check/adjust	Check/adjust	Check/change*
Ebike system diagnostics and report if available	Check/adjust	Check/adjust	Check/adjust	Print / Email*	Check/adjust	Check/adjust	Check/adjust	Print / Email*
Kill switch	Check/Replace	Check/Replace	Check/Replace	Check/Replace	Check/Replace	Check/Replace	Check/Replace	Check/Replace
Electric motor / Drive unit	Check/adjust	Check/adjust	Check/adjust	Service*	Check/adjust	Check/adjust	Check/adjust	Service*
Battery maintenance (check battery holds charge and terminals/pins are straight and not damaged) **	Check/adjust	Check/adjust	Check/adjust	Check/Adjust*	Check/adjust	Check/adjust	Check/adjust	Check/Adjust*
Brake pad wear (no less than 2.5mm - plate and pad combined)	Check/Change	Check/Change	Check/Change	Check/Change*	Check/Change	Check/Change	Check/Change	Check/Change*
Parking brakes	Check/adjust	Check/adjust	Check/adjust	Check/adjust*	Check/adjust	Check/adjust	Check/adjust	Check/adjust*
Brake disc wear (no less than 1.8mm)	-	Check/change	Check/change	Check/change	Check/change	Check/change	Check/change	Check/change
Drive shaft alignment and bearings* (damage/noise/lubrication)	-	Check/change	Check/change	Change*	Check/change	Check/change	Check/change	Change*
Bike alignment and vehicle tracking	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust	Check/Adjust
Shock absorbers for leaks/misting	-	-	-	Check/change*	-	-	-	Check/change*
Wheel inspection / Spokes (damage)	Check/change	Check/change	Check/change	Check/change*	Check/change	Check/change	Check/change	Check/change*
Seat (good quality and can be adjusted)	-	-	-	Check/change*	-	-	-	Check/change*
Locks & latches (function/lubrication)	-	-	-	Check/change	-	-	-	Check/change
Half-shaft hub retaining bolts	-	-	-	Change	-	-	-	Change
Sprocket wear (dif/motor/crank)	-	-	-	Check/change*	Check/Change	Check/Change	Check/Change	Check/change*
Play in head (stem) and bottom bracket	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust
Visible electric cables and connectors	Check/adjust	Check/adjust	Check/adjust	Check/adjust*	Check/adjust	Check/adjust	Check/adjust	Check/adjust*
Play on wheels (Mounts)	-	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust
Steering and joints (function/lubrication)	-	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust
Wheel nuts	Check/Torque	Check/Torque	Check/Torque	Check/Torque*	Check/Torque	Check/Torque	Check/Torque	Check/Torque*
Headlights*, indicators, wipers & horn	Check/adjust	Check/adjust	Check/adjust	Check/adjust*	Check/adjust	Check/adjust	Check/adjust	Check/adjust*
Bodywork	-	-	-	Check/Fix	-	-	-	Check/Fix
Cargohold integrity & function	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust
Tyre pressure	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust	Check/adjust
Hub gear / Gears	-	Check/adjust	Check/adjust	Service	Check/adjust	Check/adjust	Check/adjust	Service
Brake fluid	Check/adjust	Check/adjust	Check/adjust	Change*	Check/adjust	Check/adjust	Check/adjust	Change*
Brake lines	Check/adjust	Check/adjust	Check/adjust	Check/adjust*	Check/adjust	Check/adjust	Check/adjust	Check/adjust*